


## Aluminium Floor Bunding Installation Guide

### WHAT YOU NEED

- Aluminium Floor Bunding 1200mL with predrilled holes
- 4 x Dynabolts (10 x 75mm)
- Fulaprene sealant tubes
- Caulk gun
- Permanent marker or chalk
- Hammer drill with masonry drill bit
- Fine tooth saw
- Socket set
- Vacuum cleaner or broom



### INSTRUCTIONS

1. To begin, ensure that the installation surface is clean and free of oil and grease
2. Mark out the floor where the floor bund is to be installed with a permanent marker or chalk
3. Using the line as a guide, measure the length required for each section of the bund and cut to match. These can be mitred to change direction
4. Liberally apply Fulaprene sealant underneath the floor bund and on the ends of each adjoining section
5. Place the prepared section of floor bund along the line
6. Using the hammer drill and the predrilled holes in the floor bund as a guide, drill a 10mm diameter hole into the floor, approximately 70mm deep. Vacuum away resulting dust.
7. Insert dynabolts through the bunding and tighten using the socket set until the top is below the surface in the Aluminium floor bunding
8. Run a bead of Fulaprene sealant along the inside edge of the bund to provide a final seal
9. Repeat this process until all lengths are in place and the bund has been created.
10. Once the sealant is cured, your long term containment solution is now in place for a safer workplace.

